



Luxury Doors

Installation instructions for a hinged door;

Notes:

- We recommend that you hire a qualified builder or carpenter for your door installation for a professional finish.
- For your safety, please use the correct PPE equipment.
- Our doors require two people for lifting

Basic Installation Instructions:

1. Measure & check squareness of Jamb to compare with measure of new door
2. If required plane the new door to suit the existing door jamb, allowing for a gap of 3mm to the top, left & right. The bottom should allow for a 5mm gap after the flooring allowance if there is still flooring to be installed. NOTE: We recommend a maximum of 20mm to be planed on sides, top & bottom, keep in mind that the design will need to remain centred after any trimming.
3. Hinges to be fitted to door, as all of our doors are solid, we recommend that 3 hinges are used. Hang door and ensure that suitable gap sizing will allow your new door to swing without obstruction
4. Door hardware to be fitted, please follow manufacturers instructions for installation of door hardware.
5. Once door is perfectly fitted, remove the door to apply the finished coats of paint, ensure suitable masking is applied to any mirror surfaces prior to painting. Ensure that the hinge check outs, top and bottom edge of door are also sealed with paint.
6. Once paint has completely dried, re-hang your new door & re-fit door hardware.

